



# OfficePal K30W



**Manual**

# Safety Instructions

This device is intended as a keyboard for use with a PC. For your own safety, be sure to read the instructions below before using the device. If the product is damaged due to improper use or non-compliance with the safety instructions, the manufacturer's guarantee will be void.

## **CAUTION!**

- Ensure that the device is not damaged before use.
- Only use the device indoors in areas with normal humidity.
- Ensure that the device does not come into contact with moisture or liquids.
- Only clean the device with a dry cloth.
- Connect this device only with compatible, intended cables and only to other compatible, intended devices.
- The device does not contain any components that require maintenance. Opening the keyboard housing will result in the loss of the guarantee.

# Specifications

## General:

■ Type:	Wireless Keyboard
■ Switch Technology:	Rubber Dome (Scissor Switch)
■ Number of Keys:	110 ISO
■ Keycap Material:	ABS
■ Keycap Legend:	Print
■ Wireless Communication:	2.4 GHz
■ Max. Wireless Range:	10 m
■ Frequency Range:	2.405 – 2.470 GHz
■ EIRP Transmit Power:	6 dBm
■ Operating Temperature:	-5 to +45 °C
■ Max. Polling Rate:	125 Hz
■ Form Factor:	3-Block Layout
■ Detachable Charging Cable:	✓
■ Weight without Cable:	549 g
■ Weight incl. Cable:	580 g
■ Dimensions (L x W x H):	435 x 130 x 15 mm
■ Supported Operating Systems:	Windows/macOS

## Battery Properties:

■ Type:	Lithium-Ion
■ Capacity:	350 mAh
■ Battery Life:	Max. 110 Hours
■ Recharge Options:	Wired (USB)



## Cable and Connectors:

■ Connector:	USB-C to USB-A
■ Gold-Plated USB Plug:	✓
■ Cable Length:	180 cm




## Package Contents:

■ OfficePal K30W, USB Nano Receiver, USB Charging Cable (180 cm)
--


# Remove USB Nano Receiver





# Connect via USB Nano Receiver



# Charge the Keyboard



# Multimedia Keys (Windows)



 +  Windows Mode



 +  Fn Lock



To unlock the function keys, press and hold down the Fn key and then press the ESC key. The additional commands of the function keys can now be executed directly without having to press the Fn key. Press the key combination again to lock the function keys and restore their original commands.



 +  Play / Pause

 +  Next Track

 +  Mute

 +  Volume -



 +  Volume +

 +  E-mail


 +  Brightness -


 +  Brightness +

 +  Web Home


 +  Search


 +  Music

 +  Previous Track



 Calculator

 Web Favorites

 Screen Lock

 Repeat

# Multimedia Keys (macOS)






 +  macOS Mode



 +  Fn Lock

To unlock the function keys, press and hold down the Fn key and then press the ESC key. The additional commands of the function keys can now be executed directly without having to press the Fn key. Press the key combination again to lock the function keys and restore their original commands.


 +  Next Track

 +  Mute


 +  Volume -

 +  Volume +



 +  Brightness -

 Screen Lock

 +  Brightness +

 Repeat

 +  Active Tasks


 +  Search

 +  Previous Track

 +  Play / Pause











# Manually Pair with Nano Receiver











The keyboard automatically pairs to the supplied nano receiver. However, if a manual pairing is necessary, press and hold down the Fn key and also press and hold down the “4” key. The red LED on the top right of the keyboard will then start flashing rapidly for 20 seconds. While the LED is flashing, insert the USB nano receiver into an available USB port on your computer. The LED will stop flashing as soon as the keyboard has been successfully connected.





# LED Indicator





    Charging





    Battery Fully Charged

    Num Lock


    Caps Lock

    Scroll Lock

    Pairing

    Low Battery

# Recycle Battery



## EU Declaration of Conformity

Sharkoon Technologies GmbH hereby declares that this device complies with the RoHS (2011/65/EU) and R.E.D (2014/53/EU) directives.

The full EU Declaration of Conformity is available on the website

[https://www.sharkoon.com/Download/Gaming/Keyboards/OfficePal\\_K30W/CE.zip](https://www.sharkoon.com/Download/Gaming/Keyboards/OfficePal_K30W/CE.zip)

Frequency Range: 2.405 – 2.470 GHz

EIRP Transmit Power:  $\leq 6$  dBm

## Legal Disclaimer

For potential loss of data, especially due to inappropriate handling, Sharkoon assumes no liability.

All named products and descriptions are trademarks and/or registered trademarks of the respective manufacturers and are accepted as protected. As a continuing policy of product improvement at Sharkoon, the design and specifications are subject to change without prior notice. National product specifications may vary.

All rights reserved especially (also in extracts) for translation, reprinting, reproduction by copying or other technical means. Infringements will lead to compensation. All rights reserved especially in case of assignment of patent or utility patent. Means of delivery and technical modifications reserved.

## Disposal of your old products

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2012/19/EU.

Please be informed about the local separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences to the environment and human health.

**Follow us on social media!**



Facebook



Instagram



YouTube



TikTok



X

**Sharkoon Technologies GmbH**

Grüninger Weg 48

35415 Pohlheim

Germany

© Sharkoon Technologies 2025



D39507  
RoHS

